

Floe Ultra 360 RGB



TT RGB Plus Software control interface


Please download TT RGB PLUS from Thermaltake's Official website.

https://www.thermaltake.com/downloads

OS compatibility: Windows 10 & Windows 11


Floe Ultra RGB Software User Interface

CONNECT



- A. After installation of TT RGB PLUS, you can find controllers on the "CONNECT" & "CONTROLLER" pages.
- B. Click the controller port to make the "Pure Plus" fan glow red lighting to pair.
- C. Drag and drop to pair the "Pure Plus" fan with the controller port.
- D. SAVE: Save the controller pairing settings.
 RESET: Reset the controller pairing.
 RESCAN: Rescan the controllers.


MYPC



Case Fan Speed Information and PWM Performance Settings.

- A. Pure Plus real-time fan speed.
- B. Fan speed settings
 - PERFORMANCE: 0% → 100%(1500rpm.)
 - SILENT: 0% (300~500 rpm.)
 - PWM: Set PWM silent (50%) to PWM performance (100%).
- C. NAME: Edit the case fan name.
- D. Controller Port number.

LIGHTING - Pure Plus




- A. Preview and edit the lighting effect.
- B. Select 23 Lighting Effects.
- C. Lighting effect settings.
- D. Color palette: select lighting color
- E. PATTERN: Set up the color pattern ring.
- F. DEFAULT: Reset the lighting effects.

CANCEL: Unselect all.

APPLY: Execute and store lighting effects.

TT RGB Plus Software control interface

LIGHTING - Floe Ultra



- A. After installation of TT RGB PLUS, you can select "Floe Ultra" on the "LIGHTING" page.
- B. Preset the CPU water block LCD.
- C. LCD DISPLAY function list.
 - GIF & JPG (Upload picture to LCD)
 - · CPU TEMP.
 - CPU FREQUENCY
 - CPU LOAD
 - GPU TEMP.
 - GPU FREQUENCY
 - GPULOAD
 - RAM SIZE
 - RAM FREQUENCY
 - RAM TEMP.
 - RAM LOAD
 - · LIQUID TEMP.
 - CAROUSEL (Switches between CPU/GPU/Liquid information)
- D. LCD visual effect settings.

Set LCD background, text and visual color, and screen brightness, or turn off the LCD screen.

UPLOAD FILE



- A. Select "UPLOAD FILE" from "LCD DISPLAY". You can upload a file to show the picture on the LCD screen.
- B. Set the LCD text information, speed, and brightness, or turn off the LCD screen.
- C. Click "UPLOAD" to upload the file. File type: gif, jpg, png, mp4, avi, mov. Max size: 20MB

SETTINGS



- A. Click the gear icon on the upper right corner to enter the "SETTINGS" menu.
- B. Upload the picture to set it as LCD boot animation. (GIF only, Max size: 5MB)
- C. Upload the picture to set it as LCD standby screen. (JPG only, Max size: 5MB)



The software interface may vary with feature updates, please download the latest software version from www.thermaltake.com

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



